



DOOR PREPARATIONS — 2-1/8" Face Bore




1. Mark door with template sheet for 2", 2-3/8" or 2-3/4" backset. The suggested height for the hardware is 38" from the floor.

***Please note directions on template.**




2. Bore a 2-1/8" hole for the door hardware. Bore the hole from both sides of the door. Bore a 15/16" or 1" hole for the latch mechanism on the edge of the door.



3. Trace latch plate on door, then chisel out from the edge of the door for the latch plate. Insert the latch and attach plate firmly with two flat head wood screws provided. On the door jamb mark the height and the vertical line exactly opposite from the latch tongue for the strike plate.

NOTE: Latch plate and cover must be flush with door edge.




4. Trace hole on the strike plate. Cut out the area on the door jamb directly behind the hole on the strike plate to a depth of about 1/2". This will allow the latch tongue to release inside the strike plate. Attach the plate firmly with two flat head wood screws provided.

Tools Needed
15/16" or 1" Bit
2-1/8" Hole Saw
Small & Medium
Screwdrivers
Chisel
Small Hammer

Reversing the Latch

2-3/8" or 2-3/4" Backset
To reverse handing, simply turn latch tongue around and attach face plate to hold in place.



2" Backset
Turn latch over for reversing door swing.